

Intelligent Mini Dome Camera

Installation Manual

(English Version)

Please read this manual carefully before installation



Content

Precaution2

Packing Instruction3

Installation Steps of Bracket4

Installation Steps of Dome Device5

Wiring Instruction6




Precaution

1. Before installing and using the dome camera, please read this manual and The Operation Manual of Intelligent Dome Camera.
2. The dome camera uses DC16V1A power supply. The rated input voltage is attached at the bottom of the camera or relevant places.
3. Interior of the Dome device is precision optical and electrical instruments. Heavy pressure, shock and other incorrect treatment should be prevented during the processes of delivery, storage and installation. Otherwise, may cause damage on product.


4. Please do not remove and disassemble any internal parts of Dome camera by yourself in order to avoid normal usage being impacted.

5. During usage, user should tolerate by all electrical safety standards and adopt the special power provided with the Dome camera. During transmission, RS-485 and video signal should be retained enough distance with high-voltage equipments or cables. When necessary, thunder-proof, surge-proof and other protecting measures should be carried out.



6. Indoor Dome is only for indoor use in order to avoid the Dome camera to be rained or be affected with humidity, etc. Please do not use the product in humid place.

7. Please do not use the product under the situations of exceeding specified temperature, humidity or power supply specifications.



8. Please do not aim the video camera at sun or extremely bright object and do not aim or monitor the video camera at bright static object for long time.
9. Please do not use strong or caustic washing lotion to clean the main body of the Dome camera. After dirt is cleaned up, please use cotton fabric to clean the acrylic cover.
10. Use the high-speed Dome camera carefully and avoid being stroked or shocked.
11. When install the Dome Camera, please install it in the place with enough holding force.
12. If dust cover with camera lens, please use special lens paper to clean up.

Installation instruction

I. Packing indication

Figure 1 is the packing indication of upper layer, while figure 2 is that of the lower layer.




Fig. 1




Fig. 2

II. Installation steps of dome device bracket

Step one: Fix the fixing bracket base to the ceiling as indicated in figure 3.




Fig. 3

Step two: install the rod as indicated in figure 4




Fig. 4

III. Installation steps of dome device

Step one: insert the connector of RJ45 cable to the dome device, as indicated in figure 5.




图 5

Step two: install the dome device, as indicated in figure 6




Fig.6



Wiring illustration

Figure 7 is the illustration of dome device, while figure 8 is the illustration of DC16V1A power supply.




Fig.7




Fig. 8